

CARE & CLEANING INSTRUCTIONS FOR SYNTHESIS & ECLIPSE

Our Synthesis and Eclipse modern weaves are easy to keep it looking like new when following these guidelines and helpful tips. Made with woven vinyl in an array of colors, it is fade-resistant and impervious to moisture, making spills and stains easily removable with normal cleaning agents. Synthesis and Eclipse are water resistant and are cleaned using wet methods. However, please do not use solvents.

GUIDELINES FOR BEST RESULTS

- **Prevention:** Dirt and stains can be avoided with a good floor mat to get rid of 85% excess dirt being tracked into your home
- **Regular Vacuuming:** Be careful to adjust rotating brushes to a higher setting to prevent fiber damage or fraying from the beater bar
- **Act quickly:** Clean spills and accidents as quickly as possible
- **Choose the color with care:** Start from the surroundings where the floor will be used
- **Utilize furniture pads** on table and chair legs
- **Prevent unnecessary wear and tear** as well as discolouration by having hard polyamide chair wheels
- **Do not use acetone** or polish for cleaning

MANUAL CLEANING

Manual cleaning may be performed on small areas and where you cannot reach with a machine.

- Start by vacuum cleaning
- Use a scrubbing brush, warm water and all-purpose cleaner with a pH of 7-8.5
- Suck up the water with a wet vacuum cleaner or dry with soft cloth/micro-fiber cloth

STAIN REMOVAL

- Treat the stain immediately by first blotting with a clean rag or cloth
- Make sure that any cleaner you use can be used on [vinyl flooring](#)
- Use a scrubbing brush and rinse with water

STAIN	CLEAN with...
Chocolate, fat, juice, cream, coffee, beer, wine	Hot water with strong cleaner
Asphalt, oil, shoe cream, chalk, ink	Chemically pure petrol
Blood	Cold water - ammonia if needed
Rust	Light acidic (pH 3-4) cleaner
Water-based glue	Hot water
Solvent-based glue	Chemically pure petrol
Marks from shoes	Rub with dry cloth
Chewing gum	Hot steam or freeze spray
Candle Wax	Boiling water between 176°F and 212°F and cloth or rag to blot water and wax away